

## Measuring the Shaft

### To measure the shaft:

- Count the number of splines
- Measure the diameter of the shaft
- Measure the inner diameter of the seal

